














□ The package includes: ○ T.B.SILENCE-PWM Series Fan*1

Screws * 4

3 pin to 4 pin adaptor * 1

Installation:

- 1. PC power off at all times during installation
- 2. Please see the right figure for the airflow directions
- 3. Install the fan on the case with the 4 screws



4. Connect the PWM 4 pin connector to a specific PWM or 3 pin 12V header on the motherboard. Or use the enclosed 3 pin to 4 pin adaptor to connect it to a 4 pin Molex from power supply. (PWM-control requires a PWM-enabled motherboard and connection so that you can adjust fan speed via BIOS-motherboard.)

PWM connector



connect to M/B



Connect to 3 pin to 4 pin



Detaching fan blades:

Carefully push out the fan blades with your thumbs in the inner area







UCTB8/12P



Reattaching the fan blades:

Press the center of the blades towards the frame until it clicks



