

Package Includes : • USB Fan * 1 • Skin Pad * 1 • Fan Guard* 1



2. Insert the fan into skin pad and pull out the USB cable and LED switch from the hole





How to attach fan guard


Place the fan guard in between the fan (exposing side) and skin pad



How to power the fan

Please do not remove the fan while it is spinning





Carefully push out the fan blades with your thumbs in the inner area.



Please keep the circular LED ring dry when using at all times





1.Fix the fan with magnets at any place that needs extra cooling

No.



2.Plug in the USB connector

Quick off function : press the button for 3 seconds for "OFF" mode
Memory function : the LED mode would remain the mode before restart



How to reattach fan blades Press the center of the blades towards the frame until it clicks





UCUR12

U. R. VEGAS

ERMAX www.enermax.com forum.enermax.com